



Video 7: The StoryPhones Headset

The StoryPhones Headset

- There are several control buttons on each Headset: the 'Play/pause' button; the 'Skip forward' button and the 'Volume' buttons.
- To play a track, simply press the 'Play' button. A green light will show and the track will play. A short press on the 'Play' button when playing will pause the track. When paused, the green light will flash.
- Another short press will start the track to play from the point at which it was paused.
- To stop play and go back to the start, press and hold the 'Play' button for around one second.
- If the Headset is stopped rather than paused for more than 30 minutes it will go to sleep to save the battery.
- To wake up the Headset from sleep mode, press and hold the 'Play' button for a few seconds until the green light comes on.

A few checks if the Headset won't play

- If the player will not play you should check that its battery is charged by plugging it into the Base Unit.
- When the player is put into the Base Unit, a yellow light will indicate that the battery is charging. This will go out once the battery is fully charged.
- Also make sure that the player is not set to remote control mode, and that there is a track on the player.

*If you would like more advice, please phone our free customer support line on **0845 652 0907***