



Video 14: Using the Remote Console

The Remote Console

The Remote Console is a loud speaking MP3 player, ideal for listening aloud. It can also be used as a remote control for the headsets and as a recording device.

There are six buttons on the Remote Console

- Play/pause button
- Skip forward and skip back buttons
- Volume buttons.
- Record and special function button

Using the buttons

- To play a track, simply press the 'Play' button. A green light will show and the track will play.
- A short press on the 'Play' button will pause the track. When paused, the green light will flash.
- Another short press again will start the track to play again from the same position.
- To stop play and go back to the start, press and hold the green button for around one second.
- A press on the 'Skip forward' button moves onto the next track. The 'Skip back' button takes you the previous track.

*If you would like more advice, please phone our free customer support line on **0845 652 0907***