



Video 13: Using the StoryPhones System in Remote Control mode

Remote Control Mode

Remote Control Mode is best used for adult led activities or for children's collaborative listening. In this mode, the Headsets are controlled remotely by the Remote Console for all function buttons except volume control.

1. Choose which Headsets you want to put into Remote Control mode and connect them to the base unit.
2. Synchronise the players and the Remote Console so that they all contain the same set of audio tracks. This may be a single Headset and the Remote Console or a number of Headsets and the Remote Console.
3. Open the settings window and select the player or all StoryPhones you wish to put into *remote control* mode. Now click on the check box to enable remote control.
4. Choose either to disable all buttons or leave volume only working on the Headsets. The children will not be able to control play and pause or skip track if these are chosen.
5. When you have set the players up, click the 'Save' button and then 'Ok' to close the settings window. You can now control the headsets by pressing the control buttons on the Remote Console.

For users with more than one Remote Console: Remote ID's

If you have multiple StoryPhones systems in your school, you will need to make sure that all of the players that you are trying to control with your Remote Console have the same Remote ID setting. This setting must be different from the Remote ID on other Remote Consoles in your school. You can change the Remote ID in the settings panel beneath the player select drop-down list.

Muting the sound

Once the system is set up in *remote control* mode, the Remote Console will automatically play through its loudspeaker. If you do not want to hear the track from the Remote Console you can simply turn down the volume or mute the Remote Console by holding down the red button and pressing the blue 'Volume down' button at the same time.

Un-muting the sound

To un-mute the sound on the Remote Console, hold down the red button and press the blue 'Volume up' button.

Alternatively, a set of wired headphones can be used by plugging them into the headphones socket on the Remote Console.

*If you would like more advice, please phone our free customer support line on **0845 652 0907***